Operating Instructions

The B-Air Vent VP-50 Centrifugal Air Mover as packaged is ready to be placed into service.

The VP-50 is intended to be used by carpet cleaning, janitorial, sanitation, water damage restoration and construction professionals for general structural surface drying and ventilating applications.
Place the unit on the ground. Plug the unit into a grounded outlet and select the desired speed.

Maintenance

WARNING: As with all electrical equipment, the unit must be disconnected from power before servicing or cleaning.

Before each use, inspect the unit for damage, blocked inlets and exhaust and for foreign material buildup.
When the Vent VP-50 is turned on, inspect the unit for excessive vibration. In the event of excessive vibration or if the fan wheel rubs against the rotomolded housing, immediately turn off the unit and have a certified technician inspect the unit.

Servicing

In order to receive service or replacement parts under warranty, you must:
a. Call for an RMA (Return Merchandise Authorization Number)
b. Have proof of purchase
Upon inspection, we will advise you of the repairs needed and the cost (if applicable). B-Air will issue repair or replacement parts depending on warranty.

Limited Warranty

Warranty covers against defects in material and craftsmanship used under normal intended use to original purchaser for a term of (1) one year from the original date of purchase including parts, labor and 1 way shipping. Housing is covered for a term of (5) five years from the date of the original purchase.
Important!
Warranty does not cover signs of misuse including, but not limited to rough handling, abuse, tampering, improper voltage use and unauthorized maintenance and repairs